

HI-Q[®] RELATIVE INTENSITY NOISE ANALYZER

The OEwaves' HI-Q[®] OE4001 Relative Intensity Noise (RIN) Analyzer offers a fully automated measurement of ultra-low RIN CW laser sources.



HI-Q[®] RIN Analyzer is capable of automatically and rapidly measuring relative intensity noise spectrum without complex setup.

This system is unique in wideband measurement. The complete system operates with ease, speed and precision via a simple graphic user interface on a dedicated PC. No additional test equipment required. The unmatched ultra-low relative intensity noise analyzer is scalable to various input wavelength bands and is available with multiple frequency range options. This system is ideal for manufacturing and research environments.

FEATURES

- Ultra-Low Relative Intensity Noise Measurement
- Fast Real-Time Measurement
- User Friendly Interface
- Simple PC-based Operation
- 3U x 19" Rack System

OPTIONAL CONFIGURATION

- Multiple Input Wavelength Bands within 740 nm – 2150 nm
- Ultra-Low Noise Floor
- Extended Frequency Range up to 40 GHz
- Excess RIN Measurement
- Extended Input Power Range
- Remote Operation
- Range Options and Upgrades

www.oewaves.com

sales@oewaves.com

RIDE THE WAVE OF INNOVATION

465 N. Halstead Street, Suite 140 Pasadena, CA 91107

HI-Q[®] RELATIVE INTENSITY NOISE ANALYZER

Measurement Advanced Status Additional About OE4001 Intensity Noise test software ready.	
OEwaves	
Frequency Center (Hz) SBW (Hz) Auto RBW? 3M WW (Hz) Auto RBW? 3M VBW (Hz) Auto RBW? 1 0 Wessurement Type Number of Files Baseline Files Measurement 0 0 0 0 0 0 0 0 0 <t< th=""><th></th></t<>	

SPECIFICATIONS	1530 – 1565 nm	
RIN System Floors ¹	-156 ± 2 dB/Hz -161 ± 2 dB/Hz -166 ± 2 dB/Hz	Total RIN Option; Ultra-low total RIN Option; Excess RIN
Optical Input Power Range	+5 to +15 dBm	SM-FC/APC
Offset Frequency Range	100MHz – 18GHz, 27GHz or 40GHz	1Hz – 100MHz available in OE4000
Measurement Types	Total RIN	Conventional measurement
	Excess RIN (Option)	Excluding shot and thermal noises
Data Storage and I/O	HDD/USB Port	
Operating Temperature Range	15°C to 35°C	
Power	110/120 or 220/240 V _{ac} ; 50/60Hz	
Size	3U x 19: Rack Mount	Larger for 40GHz option
OPTIONS		
Low or High Input Power Range ¹	Up to 15 dB within -10 to +20 dBm	
Wavelength Ranges Available ²	740 – 935 / 965 – 1065 / 1000 – 1100 / 1260 – 1360 / 1360 – 1460 / 1460 – 1530 / 1530 – 1565 / 1565 – 1625 / 1647 – 1655 / 1950 – 2150 (nm)	

1460 – 1530 / 1530 – 1565 / 1565 – 1625 / 1647 – 1655 / 1950 – 2150 (r (Consult factory for multi-wavelength range options and custom wavelength ranges)

Consult Factory (ask us about OE4000)

Note: These specifications are subject to change without notice due to OEwaves ongoing development cycle. Patents Pending.

Note: Unless otherwise noted, noise floor is optimum at maximum specified input power range.

¹Noise floor is higher with Low Power option. Consult OEwaves Sales for custom RIN floor and low

power option performance. Consult OEwaves Sales for special cases of input power < -10 dBm.

²Noise Floor for systems with E, S and L telecom bands are 2 dB (typ.) higher than C-band specifications (3 dB with O-band configurations, 5 dB for 1647 – 1655 nm band); 7-11 dB higher for Visible region, 5-6 dB for 740nm-1.1µm, and 3-4 dB for 2 µm Input Wavelength Bands. Consult OEwaves Sales for other details.

RIDE THE WAVE OF INNOVATION

Phase / Frequency Noise



+1.626.351.4200 sales@oewaves.com www.oewaves.com

465 N. Halstead Street, Suite 140 Pasadena, CA 91107

PDS-0015_C